## **Service Parts Information**

HIGH TORQUE LOW SPEED VANE MOTORS

MHT 110/130/150




Caution: To assemble cartridge, insert vanes in rotor slots at minor diameter of cam ring. Rotate cartridge (1) complete revolution prior to ass'y with bodies to prevent misalignment of springs & guide

BELOW FACE OF BODY 0.002 INCH




BEARING ASSEMBLY FOR -S1 MODEL

KEY BEARING ADAPTER MODEL SHAFT RING (\*2 REQ'D) (\*2 REQ'D) (\*2 REQ'D) MHT-110-N1-30 401623 356165 MHT-110-R1-30 334231 (\*) 373927 MHT-130-N1-30 375221 MHT-130-R1-30 356165 334231 (\*) 373927 MHT-150-N1-30 MHT-150-N1-30-S1 334582 MHT-150-R1-30 356165 334231 (\*) 373927 356176 374542 MHT-150-R1-30-S3 354379 (\*) 334231 (\*) 374542 (\*) 373927 MHT-150-N1-30-S8



## **MODEL CODE BREAKDOWN**



For satisfactory service life of these components, use full flow filtration to provide fluid which meets ISO cleanliness code 18/15 or cleaner. Selections from Vickers OFP, OFR, and OFRS series are recommended.